

Ident – Nummern – Konstante  
3740 . . . . .

**Gebrauchsanweisung**  
52 4133  
(de,en,fr,nl,es,it,pt,el,  
pl)

**Montageanweisung**  
52 4134  
(de,en,fr,nl,es,it,pt,el,  
pl,sv,no,fi,da)

1) 16 5458


2) 16 8427

3) 17 4468


4) 17 3711  
    Verde

5) 17 3712  
    Ambar

6) 17 3713  
    Rojo



## Ident – Nummern – Konstante



Pos.	****			
	Aspera	Gold Star		
	BPK1072Y	ND69NAEG		
1	14 2000	14 2001		
2	15 4315			
3	17 3748			
4		17 1011		
5				
6	26 4123			
7	05 0166	05 0166		
8	28 8253	28 8253		
9				
10				
11				
12				
13				

TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compreseur/Compresor Typ/Type/Tipo	Aspera BPK1072Y	Gold Star ND69NAEG	****	
Förderleistung/Delivery/Debit/Aspiración l/h Anlaufstrom/Starting current/Cour.démarrage/Int.arranq. A	0,47			
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm Hi/aux.	33,10			
	38,20			
Temp. Reyler/Thermostat/Termostato Typ/Type/Tipo	Danfoss 077B6181	Ranco K54-L2007		
Reglerstellung/Position/Conexión Schaltwerte/Switching values/ Valeurs de commutation/Desconex. (..abtaven' od)	MIN. MAX. ..ein/conex.°C ..aus"/descon. ..alarm'	MIN. MAX. +6° -14° -22° -11° -28° -20° -28° -10° -18°		
Füllmenge/Fill. quantity/Charge/Carga R600a	g	*	*	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.	W	79	83	
Heizung/Heater/Chauflage/Resistenc.descong. Widerstand/Resistance/Resistencia Leistung/Power/Puissance/Potencia	Ohm W			
Ventilador/Blower/Ventilateur/Ventilador Widerstand/Resistance/Resistencia	Ohm			
Magnetventil/Magnetic valve/Electrovanne/Electrovalvula Widerstand/Resistance/Resistencia Spannung/Voltage/Tension/Tensión	Ohm V			
Temp. Reyler/Thermostat/Termostato ambiente para ventilador refrigerador				

\* Siehe Typenschild / See identification plate / Voir plaquette de caractéristiques / Ver plaqueta de características